



PREPARATION




Undress to preferred comfort level and remove jewelry



Put on nose filters and hair cap - leave ears and hairline exposed

FOR SPRAY TANS



Apply a thin layer of barrier cream to hands and feet including nails

OPTIONAL



Use sticky feet/footies provided by salon to keep bottom of feet clean

Note: the FDA recommends wearing protective eyewear, nose filters, ear plugs, lip balm, and undergarments. Ask the salon staff for details.

DURING

Audio instruction and adaptive lighting will guide you through 2 easy positions



Place palms out towards the walls - keep arms slightly forward in front of you



Extend arms straight out toward the walls and create a fist with both hands



SKINCARE TREATMENTS

Wellfit solution treatment options are designed to deliver 24 hours hydration to skin, help to provide soothing relief from everyday environmental irritations, aid in replenishing vital amino acids, and assist in stimulating collagen production.

3X
WEEKLY

For optimal results, incorporate Wellfit treatments into your skincare routine at least 3 times a week.



CUSTOMIZED SPRAY TANS

Spray Tan Sessions can be customized with bronzers, scents and skincare additives. See salon for options.

For optimal results:

- Avoid getting wet for at least 6 hours post-tanning session
- Full tanning results in 24 hours
- Moisturize daily after first post-tan rinse
- Avoid harsh soaps, exfoliators and scrubbing skin until you are ready to remove your tan

WHERE TANNING MEETS SKINCARE & TECHNOLOGY



SCAN QR CODE
TO LEARN MORE!